




$D = W/2$
 D = DEPTH OF BACKER ROD
 W = WIDTH OF EXPANSION JOINT

**SHERWIN
WILLIAMS.**

HIGH
PERFORMANCE
FLOORING

sherwin-williams.com/resinflooring
 (660) 638-5089

TITLE

CRYLAFLOR FLOORING

EXPANSION JOINT DETAIL

DATE

3/25

SCALE

AS NOTED

DWG NO.

MMA-3

PROJECT